




FIXED IN PLACE - SINGLE PANEL

# INSTALL GUIDE




## PACK CONTENTS:

- U Channels [ Top, Bottom, Left, Right ]
- Matching Colour Rivets
- Shutter Pane

## WHAT YOU WILL NEED:

- Drill
- Pop Rivet Gun
- Drill Bits Suitable for Aluminium (4mm required for Rivets)
- Screw Tip Bit
- Fixing Screws (and required hardware) for securing to your reveal surface (eg. Wood, Steel, Masonry)  
- Speak to your local trade store personnel for advice




For more information visit  
[www.saltbreeze.com.au](http://www.saltbreeze.com.au)

# STEP 1


Fit the Top 35x40mm U Channel

- a. Pre-drill holes into Top Channel using diagram below
- b. Secure by screwing into reveal surface

## DRILL HOLE PLACEMENT



**T**  
Reveal edge has sticker indicating **Top (T) Channel**





# STEP 2


Fit the Bottom U Channel

- a. Pre-drill holes into Bottom Channel using diagram below  
NOTE: Continue to alternate the side in which the holes are located
- b. Secure by screwing into reveal surface

## DRILL HOLE PLACEMENT



**B**  
Reveal edge has sticker indicating **Bottom (B) Channel**





# STEP 3

Fit 1 Side U Channel NOTE: This is 12mm shorter than reveal height

- a. Pre-drill holes into Side channel using diagram below
- b. Secure by screwing into reveal surface

## DRILL HOLE PLACEMENT




# STEP 4

Place other Side U Channel onto the Shutter Panel

NOTE: Needs to be on the opposite side to the one already fitted to reveal

- This side channel is the same height as panel





## STEP 5

Repeating the same action with H-Section

- a. Insert top first, followed by bottom
- b. Push Panel and H-Section to one side



## STEP 6

Position the Shutter Panel centrally to the opening and secure.

- a. Push loose side channel against the frames opening while using the width of the shutter panel sides as (X) illustrates below to locate panel in central position;
- b. Secure in place by drilling 4mm Holes in each corner where each channel shutter panels overlap
- c. Now secure in place using pop rivet gun and rivets

