


PACK CONTENTS:

- U Channels [Top, Bottom, Left, Right]
- H-Section(s)
- Matching Colour Rivets
- Shutter Panels



WHAT YOU WILL NEED:

- Drill
- Pop Rivet Gun
- Drill Bits Suitable for Aluminium (4mm required for Rivets)
- Screw Tip Bit
- Fixing Screws (and required hardware) for securing to your reveal surface (eg. Wood, Steel, Masonry)
 - Speak to you local trade store personnel for advice


STEP 1

Fit the Top 35x40mm U Channel


- a. Pre-drill holes into Top Channel using diagram below
- b. Secure by screwing into reveal surface

Reveal edge has sticker indicating **Top (T) Channel**

DRILL HOLE PLACEMENT







STEP 2

Fit the Bottom U Channel


a. Pre-drill holes into Bottom Channel using diagram belowNOTE: Continue to alternate the side in which the holes are located

b. Secure by screwing into reveal surface

DRILL HOLE PLACEMENT







STEP 3

Fit both Side U Channels


- a. Pre-drill holes into Side channel using diagram below
- b. Secure by screwing into reveal surface


L

Reveal edge has sticker indicating **Left (L) Channel**

DRILL HOLE PLACEMENT







Reveal edge has sticker indicating **Right (R) Channel**

STEP 4

Fit first Shutter Panel in place:

- a. Slide the top edge into the Top $\ensuremath{\mathsf{U}}$ Channel first
- b. Sit the Shutter Panel into the bottom channel






STEP 5

Repeating the same action with H-Section a. Insert top first, followed by bottom

b. Push Panel and H-Section to one side

REPEAT FOR MORE PANELS & H-SECTIONS







STEP 6

Starting from the left side, overlap the edge of the

fixed channel and shutter panel(s) approx 10-15mm. a. Distribute each panel and H-Section

evenly (X), then;

 b. Secure in place by: Drilling 4mm Holes in each corner where each channel, H-Sections & shutterpanels overlap

c. Now secure in place using pop rivet gun & rivets

